


KD rev 2.1 VFD-Kundendisplay



Rückseite

1, 2, 3 = 0V
4 = TTL-Seriell in 9600Bd
6, 5 = +5V